

TOPAS[®] COC for Microfluidics and Diagnostics



TOPAS[®] Cyclic Olefin Copolymer (COC)
Your Clear Advantage

Microfluidics & TOPAS COC

- TOPAS[®] COC:
 - What is TOPAS
 - Major application areas
 - Value in microfluidics

- TOPAS[®] Polymer and Microfluidic Performance
 - Flow
 - Optics
 - Replication

- TOPAS[®] COC Diagnostic Applications
 - Various diagnostic, point of care, and lab devices

TOPAS[®] COC

High Performance Polymer for Microfluidics



Resin Design




Products



Value

- Ethylene copolymer
- Molecular weight
- Comonomer level
- Stereochemistry



- Purity
- Clarity
- Chemical Resistance
- Barrier – H₂O, ROH, more
- Heat Resistance
- Superb detail precision
- UV transmission

Unique Resin



Unique Benefits

TOPAS Advanced Polymers – Corporate Info



Business mission

- Production and sale of TOPAS® cyclic olefin copolymers (COC)



Key markets and applications

■ Optics

- Displays (light distribution, reflection, touch screen); lenses



■ Healthcare

- API / drug delivery systems; surgical instruments; diagnostics



■ Packaging

- Protective, shrink, twist, thermoforming, easy tear films



Why TOPAS[®] for Microfluidics?




- Excellent light transmission → both in visible and UV regions
- Exceptional purity and low autofluorescence
- Good chemical resistance to polar solvents → alcohols, DMSO and more
- High flow resins → ease of processing complex designs
- Excellent surface reproduction → down to submicron size (100 nm wide by 100 nm deep)

TOPAS[®] COC Value in Diagnostics



- High flow with submicron surface replication
- Outstanding optics, transparency, and clarity
- Best UV transmission of any polymer
- Chemical resistant – DMSO, alcohols, acids, more
- Low autofluorescence
- High purity, non-reactive, with extremely low extractables
- Proven solution from the industry leader
- Surface treatable
- Broad global regulatory clearance
- High dimensional stability
- Heat resistant grades for PCR, sterilization, etc.
- 3D prototyping to accelerate design process

TOPAS[®] COC - Excellent Light Transmission



The high transparency of TOPAS in the visible and near ultraviolet range is attractive for optical components


Flow: MVR of TOPAS

Grade	MVR ^(a) (cm ³ /10 min)
8007S-04	32
5013L-10	48
6013M-07	14
6015S-04	4
6017S-04	1.5

← High Flow Grades ←


(a) MVR measured at 260°C, 2.16 kg load

Optics: TOPAS 8007X10 near-UV transmission



TOPAS COC is best where light transmission at <300 nm is required

Optics: TOPAS[®] COC delivers Low Fluorescence





Description:

- Microtiter Plates for High Throughput Screening

Value Proposition:


- High transparency in the near UV range
- Specific chemical resistance (e.g. DMSO)
- High flow and precision molding
- Temperature resistance
- Dimensional stability
- Cost reduction

TOPAS Grades:

- 8007X10, 8007S-04
- 5013S-04, 5013L-10

Well density increasing; 1536 well plates now routinely available

Diagnostic Application: Microwell Array



Application:

- Diagnostic Microwell Array Slides

Value Proposition:


- Chemical resistance (e.g. alcohols, DMSO)
- Very good replication of microstructures
- High transparency in the near UV range
- Low autofluorescence
- Low birefringence
- Temperature resistance
- Biocompatibility

Material:

- 8007X10, 8007S-04
- 5013L-10, 5013S-04

3 μ wells on 6.5 μ centers

UV Application: Cuvettes



Description:

- UV Cuvettes

Value Proposition:

- High transparency in the near UV range
- Excellent optics
- High flow and precision molding
- Dimensional stability

TOPAS Grades:

- 8007X10, 8007X4

Microfluidic Application: Lab diagnostics



Application:

- Lab CDs and Biochips

Value Proposition:

- Low autofluorescence
- High transparency in the near UV range
- Chemical Resistance
- Good processing
- Very good flow
- Accurate reproduction of mold details

Material:

- 8007S-04

Microfluidic Application: Development Tool



Application:

- Microfluidic Construction Kit


Value Proposition:

- Optical properties
- High transparency in the near UV range
- Biocompatibility
- Chemical resistance (e.g. alcohols, DMSO)
- Very good flow
- Accurate reproduction of mold details
- Low autofluorescence

Material:

- 8007, 5013

Customer: thinXXS



Application:



- Diagnostic Slides

Value Proposition:

- Chemical resistance (e.g. alcohols, DMSO)
- Very good replication of microstructures
- High transparency in the near UV range
- Low autofluorescence
- Low birefringence
- Temperature resistance
- Biocompatibility

Material:

- 8007X10, 8007 X4, 8007S-04
- 5013L-10, 5013S-04



Description:

- Portable, compact analyzers for lab, office or home testing

Value Proposition:

- Credit card size chip, nanoscale
- Low leachables & extractables
- Microchannel precision molding
- Broad chemical resistance
- Breakage resistant, good optics
- Lightweight and portable

TOPAS Grades:

- 8007S-04, 5013L-10

Diagnostic Application: POC Cartridge



Description:

- Afinion Point-of-Care System for HbA1c test

Value Proposition:


- Optical properties
- Very good light transmission
- Excellent water vapor transmission rate
- Biocompatible
- Chemical resistance (e.g. alcohols, DMSO)
- Low autofluorescence

Material:

- 8007S-04

Customer: Axis-Shield

3D Prototyping of COC Microfluidic Devices



Application:

- Dolomite Fluidic Factory 3D Printer

Value Proposition:

- Immediate prototyping of microfluidic designs
- Uses industry standard TOPAS 8007S-04
- Easy to use
- Inexpensive
- Channels as small as 300 μ m

Material:

- 8007S-04

Customer: Dolomite Microfluidics

www.dolomite-microfluidics.com

TOPAS[®] 8007 film for diagnostic applications



Description:

- TOPAS films for diagnostic applications
- **Value Proposition:**
 - Excellent optical properties
 - High transparency in the near UV range
 - Low autofluorescence
 - High purity, low extractables
 - Very low water uptake
 - Design flexibility: embossable, formable
- **TOPAS Grade:**
 - 8007X10, 8007X4

Film producers: Contact us

Disclaimer



NOTICE TO USERS: To the best of our knowledge, the information contained in this publication is accurate, however we do not assume any liability whatsoever for the accuracy and completeness of such information. The information contained in this publication should not be construed as a promise or guarantee of specific properties of our products. All technical information and services of Topas Advanced Polymers, Inc. are intended for use by persons having skill and experience in the use of such information or service, at their own risk.

Further, the analysis techniques included in this publication are often simplifications and, therefore, approximate in nature. More vigorous analysis techniques and prototype testing are strongly recommended to verify satisfactory part performance. Anyone intending to rely on any recommendation or to use any equipment, processing technique or material mentioned in this publication should satisfy themselves that they can meet all applicable safety and health standards.

It is the sole responsibility of the users to investigate whether any existing patents are infringed by the use of the materials mentioned in this publication.

Properties molded parts, sheets and films can be influenced by a wide variety of factors including, but not limited to, material selection, additives, part design, processing conditions and environmental exposure. Any determination of the suitability of a particular material and part design for any use contemplated by the user is the sole responsibility of the user. The user must verify that the material, as subsequently processed, meets the requirements of the particular product or use. The user is encouraged to test prototypes or samples of the product under the harshest conditions to be encountered to determine the suitability of the materials.

Material data and values included in this publication are either based on testing of laboratory test specimens and represent data that fall within the normal range of properties for natural material or were extracted from various published sources. All are believed to be representative. These values alone do not represent a sufficient basis for any part design and are not intended for use in establishing maximum, minimum, or ranges of values for specification purposes. Colorants or other additives may cause significant variations in data values.

We strongly recommend that users seek and adhere to the manufacturer's current instructions for handling each material they use, and to entrust the handling of such material to adequately trained personnel only. Please call TOPAS Advanced Polymers, Inc. - hotline (859) 746-6447 x4400 for additional technical information. Call Customer Services at (859) 746 6447 x4402 for the appropriate Material Safety Data Sheets (MSDS) before attempting to process our products. Moreover, there is a need to reduce human exposure to many materials to the lowest practical limits in view of possible adverse effects. To the extent that any hazards may have been mentioned in this publication, we neither suggest nor guarantee that such hazards are the only ones that exist.

The products mentioned herein are not intended for use in medical or dental implants.